

Size guide – find your size

We have many sizes to choose from. Our trousers are sized in inches, not centilong. This is because we offer several fits for each size, to help you find the perfect fit. Check your measurements to ensure you get the maximum satisfaction from your garments. It's simple. When choosing sweaters and jackets, check the size of garments you already have that fit you well. Then compare them to our tables to find your size.

How to measure your trouser size.

1 Waist measurement

Using a tape measure, take your waist measurement at the height where you usually wear your jeans. Before taking the measurement, think about the type of jeans you typically wear. If they are low-waisted, measure lower down. If they are high-waisted, measure higher up. If you tend to wear your jeans at hip height, measure there. This gives you your torso measurement.


2 Length measurement

Always take the measurement on the inside part of the leg. The easiest way is to measure a pair of trousers that you know fit well. Measure from the crotch down to the bottom of the leg.

Alternatively, if you already have jeans that fit you well, you can check what size they are. The jeans size is made up of two different measurements in inches. For example, the size might be 30/32. The first number is the waist measurement and the second number is the length measurement.

Measurement table – garments

Size	Women	Men	Shirts	Sweaters	Hats	Gloves
XXS						
XS	32	44	35–36	3	53–54	6
S	34–36	46–48	37–38	4	55–56	7
M	38	48–50	39–40	5	57–58	8
L	40	52–54	41–42	6	59–60	9
XL	42	56–58	43–44	7	61–62	10
XXL	44	60–62	45–46	8	63–64	11



Care instructions

All Texstar clothes are carefully tested and easy to care for. Follow the washing instructions to maximise the garment's lifespan while caring for the environment:

- Always sort clothing according to temperature and colour. Garments marked "Wash with similar colours" may run during washing and stain other clothing. This problem usually disappears after a few washes.
- Coloured garments should always be washed at the highest recommended temperature for each garment.
- To protect zips, close them before washing.
- It is usually unnecessary to include a pre-wash in the washing cycle. Treat stubborn stains with stain remover before washing.
- Coloured clothing should be washed with special detergent for coloured fabrics to prevent fading.
- Dose the detergent according to the package instructions and your water hardness. Your local council can usually provide information on the water hardness in your area.
- Avoid detergents containing the bleaching agents sodium hypochlorite, sodium perborate or sodium percarbonate.
- Also check that your detergent is appropriate for the temperature you are washing at.
- Do not use fabric conditions.
- Most clothes benefit from being hung up to dry. Always shake and stretch them out before hanging. This is particularly important for knitted materials.
- If you choose to tumble dry clothing, stop before it is completely dry to prevent unnecessary shrinkage and wear.

Men’s sizes – trousers

NORMAL LENGTH

High-waisted trousers Inches / W	25/30	26/30	27/30	28/30	29/32	30/32	31/32	32/32	33/32	34/32	36/34	38/34	40/34	42/34	42/34	44/34	46/34
Normal C	C44		C46		C48		C50		C52		C54		C56		C58/60		C62
1 Waist	59–66 cm		63–71 cm		68–78 cm		76–86 cm		84–94 cm		92–100 cm		98–114 cm		104–119 cm		119–130 cm
2 Crotch length	78 cm		78 cm		83 cm		83 cm		83 cm		88 cm		88 cm		88 cm		88 cm
Jackets, parkas and other garments	S				M				L				XL		XXL		XXXL

LONG

High-waisted trousers Inches / W	27/32	28/32	29/34	30/34	31/34	32/34	33/34	34/34	36/36	38/36	40/36	42/36
Long C	C146		C148		C150		C152		C154		C156	
1 Waist	63–71 cm		68–78 cm		76–86 cm		84–94 cm		92–100 cm		98–144 cm	
2 Crotch length	83 cm		88 cm		88 cm		88 cm		93 cm		93 cm	
Jackets, parkas and other garments	S		M				L				XL	

SHORT

High-waisted trousers Inches / W	32/28	32/30	34/30	36/30	38/30	40/30	42/30	44/32	46/32
Short D	D88	D92	D96	D100	D104	D108	D112	D116	D120
1 Waist	76–84 cm	82–86 cm	88–94 cm	92–97 cm	95–100 cm	98–106 cm	104–112 cm	110–118 cm	114–120 cm
2 Crotch length	73 cm	78 cm	78 cm	78 cm	78 cm	78 cm	78 cm	83 cm	83 cm
Jackets, parkas and other garments	S		M	L			XL	XXL	

Women's sizes – trousers/skirts

NORMAL LENGTH

High-waisted trousers Inches / W	26/30	27/30	28/32	29/32	30/32	31/32	32/32	33/32	34/32	36/32
Normal C	C36		C38		C40		C42		C44	C46
1 Waist	68–76 cm		73–81 cm		78–86 cm		83–92 cm		88–99 cm	93–99 cm
2 Crotch length	78 cm		83 cm		83 cm		83 cm		83 cm	83 cm
Jackets, parkas and other garments	S		M		L		XL		XXL	XXXL

LONG

High-waisted trousers Inches/ W	26/32	27/32	28/34	29/34	30/34	31/34	32/34	33/34	34/34	36/34
Long C	C136		C138		C140		C142		C144	C146
1 Waist	68–76 cm		73–81 cm		78–86 cm		83–92 cm		88–99 cm	93–99 cm
2 Crotch length	83 cm		88 cm		88 cm		88 cm		88 cm	88 cm
Jackets, parkas and other garments	S		M		L		XL		XXL	XXXL

SHORT

High-waisted trousers Inches / W	25–26/31	26–27/31	28–29/31	30–31/32	32–33/32	34/32	36/32
Long C	C34	C36	C38	C40	C42	C44	C46
1 Waist	64–70 cm	68–76 cm	73–81 cm	78–86 cm	83–92 cm	88–99 cm	93–99 cm
Jackets, parkas and other garments	XS	S	M	L	XL	XL	XXL